


DESCRIPTION AND OPERATION

Item	Description
31	Low engine oil pressure warning indicator
32	Engine oil change indicator

Vehicles with Petrol Engine



Item	Description
1	Charging system indicator
2	Washer fluid level indicator
3	Malfunction indicator lamp (MIL)
4	Fuel fired booster indicator
5	Ice warning indicator
6	Low fuel level indicator
7	Left hand turn signal indicator
8	Fuel gauge
9	High beam indicator
10	Engine coolant temperature gauge
11	Right hand turn signal indicator
12	Door open indicator
13	Braking system indicator
14	Stability assist ON indicator
15	Vehicle immobiliser indicator

Item	Description
16	Powertrain warning indicator
17	Air bag warning indicator
18	Seat belt indicator
19	Anti lock braking system (ABS) warning indicator
20	Front fog lamp indicator
21	Stability assist OFF indicator
22	Message center
23	Two wheel drive indicator
24	Four wheel drive low ratio indicator
25	Anti theft indicator
26	Four wheel drive indicator
27	Gear shift indicator lamp
28	Water in fuel indicator
29	Head lamp indicator