4WD

SEC. 391•400•401

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.

